

Parallax QTI Sensor KickStart (#555-27401)




What It Can Do

- Detects differences between light and dark objects
- Proximity detection to judge relative distance to an object
- Works as an analog sensor, but can be connected to a digital I/O pin

The QTI Sensor uses an infrared light emitting diode and infrared phototransistor to provide simple but effective non-contact detection of patterns and objects. In either case, light emitted by the LED bounces off a surface or object, and is detected by the phototransistor.

For pattern detection, the sensor can differentiate between light and dark surfaces, such as a black line drawn on a piece of white paper (useful as a robot line follower).

For object detection, the sensor can judge whether it's close to an object by how much infrared light is reflected from it (useful as a tabletop edge detector).




QTI stands for *Charge Transfer Infrared*, an acronym describing how the sensor uses the charge/discharge time of a capacitor to provide a scaled output, without requiring any additional analog-to-digital circuitry.

In a working circuit, your microcontroller measures the time it takes for the QTI's capacitor to decay. This decay time is a measurement of the rate of charge transfer through the infrared phototransistor, and indicates how much infrared light is reflecting off a nearby surface.

Parts List


- QTI Sensor
- BASIC Stamp HomeWork Board, Propeller BOE, Propeller QuickStart, or Arduino Uno microcontroller (solderless breadboard as needed)
- 22 gauge solid conductor hookup wire

Basic Wiring



- Power requirements: 3.3 to 5 VDC
- Communication: Analog output of capacitor decay time depending on level of infrared reflectivity
- Dimensions: 1.25 x 0.37 in (31.7 x 9.4 mm)

Important! The labeling on the QTI Sensor refers to the colors of a 3-wire servo extension wire: **Black**, **Red**, and **White**. The QTI does not follow the typical arrangement of 3-wire connections where the center (red) wire is power. Be sure not to reverse the +V and Gnd wires!



Program KickStarts


Each of the example programs displays current value from the QTI sensor as a number.

- The *lower* the number, the *lighter* the surface. Or for object detection, the *closer* the sensor is to the object.
- The *higher* the number, the *darker* the surface. Or for object detection, the *farther* the sensor is to the object.

The range of values depends on the microcontroller (due to how the microcontroller measures the capacitor transfer decay time), but is typically about 30 to 2000. The range will also depend on the reflectivity of the object.

Some objects, like the black antistatic foam used to protect electronic circuit boards, reflect little or no infrared light, and the QTI cannot reliably detect these.

BASIC Stamp HomeWork Board



```

' {$STAMP BS2}
' {$PBASIC 2.5}

SnsrIn CON 9          ' Line sensor input (R)
Duration VAR Word    ' Holds duration value

Read_Sensor:
  HIGH SnsrIn        ' Discharge QTI cap
  PAUSE 1             ' Wait 1 ms
  RCTIME SnsrIn, 1, Duration ' Read sensor value


  Display:           ' Display value
  DEBUG HOME
  DEBUG "-----", CR
  DEBUG DEC Duration, CLREOL
  PAUSE 250         ' Wait 250 ms, repeat
  GOTO Read_Sensor

```


Note: When this program is run, the BASIC Stamp Debug Terminal will automatically open.

Note: Depending on surface reflectivity, values will range from about 60 to 3400.

Propeller BOE and Propeller QuickStart



Propeller BOE Wiring Diagram



Propeller QuickStart Wiring Diagram

OBJ

```

debug : "FullDuplexSerial"
rc    : "RCTime"

```

CON

```

_clkmode = xtall + pll16x
_xinfreq = 5_000_000

```

VAR

```

long RCValue

```

PUB Go

```


debug.start(31, 30, 0, 115200)
RCValue := 0

repeat
  rc.rctime(0, 1, @RCValue)      ' Get RC value on 0
  debug.dec(RCValue / 100)      ' Display results
  debug.tx(13)
  WaitCnt(ClkFreq / 4 + Cnt)    ' Delay 250ms, repeat

```

Note: This program uses the FullDuplexSerial object library, which is included with the Propeller Tool software download. To view the results of the demonstration, after uploading is complete run the Parallax Serial Terminal from the Run menu, or press F12. Momentarily depress the Reset button on the Propeller QuickStart board to restart the program. Depending on surface reflectivity, values will range from about 3 to 2000.

Arduino Uno



```

void setup() {
  Serial.begin(9600);
}

void loop() {
  Serial.println(RCTime(2)); // Connect to pin 2, display results
  delay(250);               // Wait 250 ms
}

```

```
}  
  
long RCTime(int sensorIn){  
    long duration = 0;  
    pinMode(sensorIn, OUTPUT);    // Make pin OUTPUT  
    digitalWrite(sensorIn, HIGH); // Pin HIGH (discharge capacitor)  
    delay(1);                     // Wait 1ms  
    pinMode(sensorIn, INPUT);     // Make pin INPUT  
    digitalWrite(sensorIn, LOW);  // Turn off internal pullups  
    while(digitalRead(sensorIn)){ // Wait for pin to go LOW  
        duration++;  
    }  
    return duration;  
}
```

Note: To view the results of the demonstration, after uploading is complete click the Serial Monitor icon in the Arduino IDE. This displays the Serial Monitor window. Momentarily depress the Reset button on the Arduino board to restart the sketch.

Note: Depending on surface reflectivity, values will range from about 40 to 1300.

For More Information

- Visit the full documentation for the [QTI Sensor \(#555-27401\)](#), available from its product page.
- The [QTI Line Follower AppKit \(#28108\)](#) contains four QTI sensors, plus mounting hardware to attach to the BOE-Bot robot chassis, and is specifically designed to provide line following capability.
- The [Infrared Line Follower Kit \(#28304\)](#) is a single module with eight integrated infrared sensors, and is also designed to provide line following capability to the BOE-Bot robot chassis.